edénfantasys



Amorist

PRODUCT MANUAL

10 come hither motion modes

Comfortable grip

Waterproof IPX6

Made from silicone and ABS plastic

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB magnetic charging cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on) or power bank.
- The slow, intermittent glow indicates charging in progress.
- A full charge takes up to 80 minutes for 70 minutes of play.
- Do not use the device while charging.



Magnetic USB charging port

How To Use

- Hold the button to turn the toy on/off.
- Press the M button quickly to cycle through 10 come hither motion modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352