



Impulse

PRODUCT MANUAL

13 massage modes

Squeezable panel for controlled tightness

Flips open for easy cleaning

Two realistic openings

3D textured tunnel

Made from skin-like TPE material and ABS plastic

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 100 minutes for 110 minutes of play.
- Do not use the device while charging.



Magnetic charging port

How To Use

- Hold the **⏻** button to turn on/off.
- Press it quickly to cycle through 9 massage modes.
- Press the **M** button quickly to cycle through 4 massage modes.
- Squeeze the squishy side panel for a tighter feel.
- Turn to use the desirable opening.



Power button

Cleaning and Care

- Flip open for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.



Cleaning and Care

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352