



Rose passion

PRODUCT MANUAL

10 thrusting modes


10 licking modes

Waterproof IPX7

Made from silicone



How To Use


- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 150 minutes for 60 minutes of play.
- Do not use the device while charging.



Magnetic
charging port

How To Use

- Hold the  button to turn on/off for standby mode. The LED light will light up.
- Press it quickly to cycle through 10 thrusting modes.
- Press the  button quickly to cycle through 10 licking modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lubes only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352