



7 thrusting modes

10 massage modes

Thrusting depth up to 1.75"

Strong suction cup

Adjustable angle

Made from silicone and ABS plastic


Sweet emotion

PRODUCT MANUAL

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge for the sex machine takes up to 2 hours for 1 hour of play.
- Do not use the device while charging.

USB
charging port



Before Use

- Screw the machine to the suction cup base.



- Attach the suction cup stand to a smooth horizontal surface.
- Pull the latch down to secure the suction cup.





Suction cup

- Adjust the angle.
- Tighten the knob to hold the position.
- Loosen the knob to change the angle.

Tension knob



How To Use

- Hold the  button to turn the toy on/off.
- Press it quickly to cycle through 7 thrusting speeds.
- Press the  button quickly to cycle through 10 massage modes.
- Hold it to turn the massage mode off.



Cleaning and Care

- Unscrew the machine from the suction cup base for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the shaft before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the corrugated part and control unit as they are not waterproof. Wipe them down with the wet cloth/tissue and dry it out completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352